

Python 绘图以及文件的基本操作

<https://pypi.org/>

Python Package Index (PyPI)

# Python 绘图库 Matplotlib

**CMD** 以管理员身份运行

```
pip install -U pip setuptools
pip install matplotlib
```

```
import numpy as np
from matplotlib import pyplot as plt
```

```
x = np.arange(1,11)
y = 2 * x + 5
plt.title("Matplotlib demo")
plt.xlabel("x axis caption")
plt.ylabel("y axis caption")
plt.plot(x,y) plt.show()
```

<https://matplotlib.org/>

<https://matplotlib.org/tutorials/index.html#introductory>

```
import matplotlib.pyplot as plt
import numpy as np
x = np.linspace(0, 2, 100)

plt.plot(x, x, label='linear')
plt.plot(x, x**2, label='quadratic')
plt.plot(x, x**3, label='cubic')

plt.xlabel('x label')
plt.ylabel('y label')

plt.title("Simple Plot")

plt.legend()

plt.show()
```

<https://matplotlib.org/tutorials/introductory/usage.html#sphx-glr-tutorials-introductory-usage-py>

```
numpy.linspace(start, stop, num=50, endpoint=True, retstep=False, dtype=None)
```

增加中文的支持:

```
#coding=utf-8
```

```
#coding=utf-8
```

```
import matplotlib.pyplot as plt
```

```
plt.rcParams['font.sans-serif']=['SimHei'] #用来正常显示中文标签
```

```
plt.rcParams['axes.unicode_minus']=False #用来正常显示负号
```

```
import numpy as np
```

```
x = np.linspace(-2, 2, 200)
```

```
plt.plot(x, x, label='y=x')
```

```
plt.plot(x, x**2, label='y=x^2')
```

```
plt.plot(x, x**3, label='y=x^3')
```

```
plt.xlabel('x 轴')
```

```
plt.ylabel('y 轴')
```

```
plt.title("简单绘图")
```

```
plt.legend()
```

```
plt.show()
```

```
np.arange()
```

函数返回一个有终点和起点的固定步长的排列，如[1,2,3,4,5]，起点是1，终点是5，步长为1。

参数个数情况： np.arange()函数分为一个参数，两个参数，三个参数三种情况

1) 一个参数时，参数值为终点，起点取默认值0，步长取默认值1。

2) 两个参数时，第一个参数为起点，第二个参数为终点，步长取默认值1。

3) 三个参数时，第一个参数为起点，第二个参数为终点，第三个参数为步长。其中步长支持小数

```
#coding=utf-8
```

```
import matplotlib.pyplot as plt
```

```
import matplotlib.pyplot as plt1
```

```
plt.rcParams['font.sans-serif']=['SimHei'] #用来正常显示中文标签
```

```
plt.rcParams['axes.unicode_minus']=False #用来正常显示负号
```

```
import numpy as np
```

```
x = np.linspace(-2, 2, 200)
```

```
y=np.sin(x)
```

```
plt.plot(x, x, label='y=x')
```

```
plt.plot(x, x**2, label='y=x^2')
```

```
plt.plot(x, x**3, label='y=x^3')
```

```
plt.xlabel('x 轴')
```

```
plt.ylabel('y 轴')
```

```
plt.title("简单绘图")
```

```
plt.legend()
plt1.plot(x,y)
```

```
plt.show()
plt1.show()
```

python 可视化库 matplotlib 的显示模式默认为阻塞 ( block ) 模式

plt.show() 之后不会执行

plt.ion() 这个函数, 使 matplotlib 的显示模式转换为交互 ( interactive ) 模式

plt.show() 之后继续执行

plt.ioff() 关闭交互模式

plt.ion() 打开交互模式

```
import matplotlib.pyplot as plt
plt.ion()
plt.plot([1.6, 2.7])
plt.plot([3, 2])
```

# 创建一个画布

```
plt.figure()
```

# 在 figure 下线

```
plt.plot(x, y1, "-o") # 实线
```

```
plt.plot(x, y2, "--o") # 虚线
```

```
plt.plot(x, y3, "-.o") # 虚点线
```

```
plt.plot(x, y4, ":o") # 点线
```

# 展现画布

```
plt.show()
```

```
plt.plot(x, y1, "-.") # 点
```

```
plt.plot(x, y2, "-.") # 像素点
```

```
plt.plot(x, y3, "-o") # 圆点
```

'^' 上三角点

'v' 下三角点

'<' 左三角点

'>' 右三角点

```
plt.plot(x, y1, "-^")
```

```
plt.plot(x, y2, "-v")
```

```
plt.plot(x, y3, "-<")
```

```
plt.plot(x, y4, "->")
```

'1' 下三叉点

'2' 上三叉点

'3' 左三叉点

'4' 右三叉点

```
plt.plot(x, y1, "-1")  
plt.plot(x, y2, "-2")  
plt.plot(x, y3, "-3")  
plt.plot(x, y4, "-4")
```

's' 正方点

'p' 五角点

'\*' 星形点

'h' 六边形 1

'H' 六边形 2

```
plt.plot(x, y1, "-s")  
plt.plot(x, y2, "-p")  
plt.plot(x, y3, "-*")  
plt.plot(x, y4, "-h")  
plt.plot(x, y5, "-H")
```

'+' 加号点

'x' 乘号点

'D' 实心菱形点

'd' 细菱形点

'\_' 横线点

'|' 竖线点

```
plt.plot(x, y1, "-+")  
plt.plot(x, y2, "-x")  
plt.plot(x, y3, "-D")  
plt.plot(x, y4, "-d")  
plt.plot(x, y5, "-_")
```

color="green" 指定颜色为绿色

linestyle="dashed" 指定线形为 dashed 类型

marker="o" 指定标记类型为 o 点

markerfacecolor="blue" 指定标记的颜色为蓝色

markersize=20 指定标记的大小为 20

```
plt.plot(x, y1, "-P")  
plt.plot(x, y2, "-|")  
plt.plot(x, y3, color="#000000")  
plt.plot(x, y4, "-o", markersize=20)  
plt.plot(x, y5, "-^", markerfacecolor="blue")
```

散点图

```
plt.scatter(x, y, s, c, marker, alpha)
```

x,y: x 轴与 y 轴的数据

s: 点的面积

c: 点的颜色

marker: 点的形状

alpha: 透明度

随机数

```
x = np.random.randn(N)
```

```
y2 = x + np.random.randn(N)*0.5
```

1.plot(x, y, marker='D')表示绘制折线图，marker 设置样式菱形。

2.scatter(x, y, marker='s', color='r')绘制散点图，红色正方形。

3.bar(x, y, 0.5, color='c')绘制柱状图，间距为 0.5，原色。

4.hist(data,40,normed=1,histtype='bar',  
facecolor='yellowgreen',alpha=0.75)直方图。

5.设置 x 轴和 y 轴的坐标值：

```
xlim(-2.5, 2.5) #设置 x 轴范围 ylim(-1, 1) #设置 y 轴范围
```

6.显示中文和负号代码如下：

```
plt.rcParams['font.sans-serif']=['SimHei'] #用来正常显示中文标签
```

```
plt.rcParams['axes.unicode_minus']=False #用来正常显示负号
```

```
from matplotlib import pyplot as plt
```

```
import numpy as np
```

```
import math
```

```
x=np.linspace(-10,10,100)
```

```
fig = plt.figure()
```

```
ax1 = fig.add_subplot(231)
```

```
plt.plot(x,x)
```

```
plt.sca(ax1)
```

```
ax2 = fig.add_subplot(232)
```

```
plt.plot(x,x*x)
```

```
plt.sca(ax2)
```

```
ax3 = fig.add_subplot(233)
```

```
plt.plot(x,x**3)
```

```
plt.sca(ax3)
```

```
ax4 = fig.add_subplot(234)
```

```
plt.plot(x,np.sin(x))
```

```
plt.sca(ax4)
ax5 = fig.add_subplot(235)
plt.plot(x,np.cos(x))
plt.sca(ax5)
ax6 = fig.add_subplot(236)
plt.plot(x,x*x+x**3)
plt.sca(ax6)
plt.grid(True)
plt.show()
```




a.py - C:/Python/Python38/a.py (3.8.1)

File Edit Format Run Options Window Help

```
from matplotlib import pyplot as plt
import numpy as np
import math
x=np.linspace(-10,10,100)
```

```
fig = plt.figure()
ax1 = fig.add_subplot(231)
plt.plot(x,x)
plt.sca(ax1)
ax2 = fig.add_subplot(232)
plt.plot(x,x*x)
plt.sca(ax2)
ax3 = fig.add_subplot(233)
plt.plot(x,x**3)
plt.sca(ax3)
ax4 = fig.add_subplot(234)
plt.plot(x,np.sin(x))
plt.sca(ax4)
ax5 = fig.add_subplot(235)
plt.plot(x,np.cos(x))
plt.sca(ax5)
ax6 = fig.add_subplot(236)
plt.plot(x,x*x+x**3)
plt.sca(ax6)
plt.grid(True)
plt.show()
```

Figure 1



x=-8.7379 y=0.0157046




## Python 的输入输出，文件目录小结

- 1, 键盘输入
  - 2, 打印输出（显示器输出）
  - 3, 文件夹的建立
  - 4, 文件夹的命名
  - 5, 文件夹的删除
  - 6, 文件的删除
  - 7, 文件的输入
  - 8, 文件的输出
- 
- 


### 1, 键盘输入

```
str01=input("Please input a string:")  
print(str01)
```



将输入的字符串转换为整数

```
str01=input("Please input a string:")  
a=int(str01)  
b=a+10  
print(str01)  
print(a)  
print(b)
```





2, 打印输出（显示器输出）


3, 文件夹的建立

在 C 盘根目录下建立名为 `pytest` 的文件夹:

```
import os
os.chdir("c:/")
os.mkdir("pytest")
```



```
import os
os.chdir("c:/")
os.mkdir("pytest1")
os.chdir("/pytest1")
a=os.getcwd()
print(a)
```



#### 4, 文件夹的命名

```
os.rename( "test1.txt", "test2.txt" )
```

#### 5, 文件夹的删除


```
os.rmdir("pytest1"): 删除文件夹
```

#### 6, 文件的删除

```
import os
os.chdir("c:/")
os.chdir("/pytest1")
a=os.getcwd()
print(a)
os.remove("a.txt")
os.chdir("c:/")
```

```
os.rmdir("pytest1")
```

`os.remove("a.txt")`: 删除文件





`getcwd()`方法显示当前的工作目录

## 7, 文件的输入

# 打开一个文件

```
fp = open("c:/pytest/a.txt", "r+")
print("文件名: ", fp.name)
print("是否已关闭 :", fp.closed)
print("访问模式 :", fp.mode)
str=fp.read(5)
```

```
fp.close()
print(str)
```




建立一个空的文件 a.txt 供程序调用。

## 8. 文件的输出

```
# 打开一个文件
fp = open("c:/pytest/a.txt", "w")
print("文件名:", fp.name)
```


```
print("是否已关闭 :", fp.closed)
print("访问模式 :", fp.mode)
fp.write("hello,python");
fp.close()
```



OPENCV & python & 机器视觉

[https://docs.opencv.org/4.2.0/d6/d00/tutorial\\_py\\_root.html](https://docs.opencv.org/4.2.0/d6/d00/tutorial_py_root.html)

软件安装  
首先安装 python



Numpy package (for example, using `pip install numpy` command).

Matplotlib (`pip install matplotlib`) (Matplotlib is optional, but recommended since we use it a lot in our tutorials).



```
管理员: C:\Windows\system32\cmd.exe
版权所有 (c) 2009 Microsoft Corporation。保留所有权利。

C:\Users\Administrator>pip install numpy
Requirement already satisfied: numpy in c:\python\python38\lib\site-packages (1.18.1)

C:\Users\Administrator>pip install matplotlib
Requirement already satisfied: matplotlib in c:\python\python38\lib\site-packages (3.1.3)
Requirement already satisfied: pyparsing!=2.0.4,!=2.1.2,!=2.1.6,>=2.0.1 in c:\python\python38\lib\site-packages (from matplotlib) (2.4.6)
Requirement already satisfied: python-dateutil>=2.1 in c:\python\python38\lib\site-packages (from matplotlib) (2.8.1)
Requirement already satisfied: cyclor>=0.10 in c:\python\python38\lib\site-packages (from matplotlib) (0.10.0)
Requirement already satisfied: numpy>=1.11 in c:\python\python38\lib\site-packages (from matplotlib) (1.18.1)
Requirement already satisfied: kiwisolver>=1.0.1 in c:\python\python38\lib\site-packages (from matplotlib) (1.1.0)
Requirement already satisfied: six>=1.5 in c:\python\python38\lib\site-packages (from python-dateutil>=2.1->matplotlib) (1.14.0)
Requirement already satisfied: setuptools in c:\python\python38\lib\site-packages (from kiwisolver>=1.0.1->matplotlib) (45.2.0)
```

之前已经安装过了。


小知识：如何查找 python 环境中安装了什么？

命令：

pip list

```
C:\Users\Administrator>pip list
Package            Version
-----
cyclor              0.10.0
kiwisolver          1.1.0
matplotlib          3.1.3
numpy               1.18.1
pip                 20.0.2
pyparsing           2.4.6
python-dateutil     2.8.1
setuptools          45.2.0
six                 1.14.0

C:\Users\Administrator>
```

A screenshot of a Python 3.8.1 Shell window. The title bar reads "Python 3.8.1 Shell". The menu bar includes "File", "Edit", "Shell", "Debug", "Options", "Window", and "Help". The main text area shows the following output: "Python 3.8.1 (tags/v3.8.1:1b293b6, Dec 18 2019, 23:11:46) [MSC v.1916 64 bit D64] on win32", "Type 'help', 'copyright', 'credits' or 'license()' for more information.", and the command prompt ">>> import numpy" followed by another ">>>" on the next line, indicating the command was executed successfully.

```
Python 3.8.1 (tags/v3.8.1:1b293b6, Dec 18 2019, 23:11:46) [MSC v.1916 64 bit
D64] on win32
Type "help", "copyright", "credits" or "license()" for more information.
>>> import numpy
>>>
```


确认 numpy 是正确安装并可以使用。

[https://sourceforge.net/projects/opencvlibrary/files/4.2.0/opencv-4.2.0-vc14\\_vc15.exe/download](https://sourceforge.net/projects/opencvlibrary/files/4.2.0/opencv-4.2.0-vc14_vc15.exe/download)

下载并解压

C:\opencv001\opencv\build\python\cv2\python-3.8

复制文件 cv2.pyd 到 C:\Python\Python38\Lib\site-packages 中



以上官方提供的方法可能会由于版本的不匹配不能安装，此时用下面的语句安装：

```
pip install opencv_python
```





原图为彩色图像，打开为黑白图像。

代码如下：

```
import numpy as np
import cv2 as cv
img=cv.imread('c:/a.jpg',0)
cv.imshow('image',img)
cv.waitKey(0)
cv.destroyAllWindows()
```




`img=cv.imread('c:/a.jpg',0)` 的参数含义：1：表示彩色,0：表示灰度 or -1

[`cv.IMREAD\_COLOR`](#) : Loads a color image. Any transparency of image will be neglected. It is the default flag.

[`cv.IMREAD\_GRAYSCALE`](#) : Loads image in grayscale mode

[`cv.IMREAD\_UNCHANGED`](#) : Loads image as such including alpha channel



彩色图像

将图像写入文件中

```
import numpy as np
import cv2 as cv
img=cv.imread('c:/a.jpg',0)
cv.imwrite('c:/a1.jpg',img)
cv.imshow('image',img)
cv.waitKey(0)
cv.destroyAllWindows()
```



原来彩色的图像，变成了灰度的图像了，这个可以作为图像转换的小应用。

使用 **Matplotlib** 库进行图像的显示，更多的显示方法，更多的参数选择，比如放大等





代码如下：

```
import numpy as np
import cv2 as cv
from matplotlib import pyplot as plt

img=cv.imread('c:/a.jpg',0)
plt.imshow(img,cmap='gray',interpolation='bicubic')
plt.xticks([],plt.yticks([]))
plt.show()
```

[https://matplotlib.org/api/pyplot\\_api.html](https://matplotlib.org/api/pyplot_api.html)

[https://blog.csdn.net/du\\_shuang/article/details/84111250](https://blog.csdn.net/du_shuang/article/details/84111250)

视频流的获取

```
import numpy as np
import cv2 as cv
cap = cv.VideoCapture(0)
if not cap.isOpened():
    print("Cannot open camera")
    exit()
while True:
    # Capture frame-by-frame
    ret, frame = cap.read()
    # if frame is read correctly ret is True
    if not ret:
        print("Can't receive frame (stream end?). Exiting ...")
        break
    # Our operations on the frame come here
    gray = cv.cvtColor(frame, cv.COLOR_BGR2GRAY)
    # Display the resulting frame
    cv.imshow('frame', gray)
    if cv.waitKey(1) == ord('q'):
        break
# When everything done, release the capture
cap.release()
cv.destroyAllWindows()
```

```
a.py - C:/Python/Python38/a.py (3.8.1)
File Edit Format Run Options Window Help

import numpy as np
import cv2 as cv
cap = cv.VideoCapture(0)
if not cap.isOpened():
    print("Cannot open camera")
    exit()
while True:
    # Capture frame-by-frame
    ret, frame = cap.read()
    # if frame is read correctly ret is True
    if not ret:
        print("Can't receive frame (stream end?). Exiting ...")
        break
    # Our operations on the frame come here
    gray = cv.cvtColor(frame, cv.COLOR_BGR2GRAY)
    # Display the resulting frame
    cv.imshow('frame', gray)
    if cv.waitKey(1) == ord('q'):
        break
# When everything done, release the capture
cap.release()
cv.destroyAllWindows()
```



CV\_GRAY2RGB 是 gray 到 RGB  
CV\_BGR2GRAY,  
CV\_RGB2GRAY,  
CV\_GRAY2BGR,  
CV\_GRAY2RGB

色彩空间转换的模式，该 code 来实现不同类型的颜色空间转换。

比如 CV\_BGR2GRAY 表示转换为灰度图，

CV\_BGR2HSV 将图片从 RGB 空间转换为 HSV 空间。

其中当 code 选用 CV\_BGR2GRAY 时，dst 需要是单通道图片。当 code 选用 CV\_BGR2HSV 时，对于 8 位图，需要将 RGB 值归一化到 0-1 之间。这样得到 HSV 图中的 H 范围才是 0-360，S 和 V 的范围是 0-1

## 1、RGB 和 BGR（opencv 默认的彩色图像的颜色空间是 BGR）颜色空间的转换

cv::COLOR\_BGR2RGB  
cv::COLOR\_RGB2BGR  
cv::COLOR\_RGBA2BGRA  
cv::COLOR\_BGRA2RGBA

## 2、向 RGB 和 BGR 图像中增添 alpha 通道

cv::COLOR\_RGB2RGBA  
cv::COLOR\_BGR2BGRA

## 3、从 RGB 和 BGR 图像中去除 alpha 通道

cv::COLOR\_RGBA2RGB  
cv::COLOR\_BGRA2BGR

## 4、从 RGB 和 BGR 颜色空间转换到灰度空间

cv::COLOR\_RGB2GRAY  
cv::COLOR\_BGR2GRAY

cv::COLOR\_RGBA2GRAY  
cv::COLOR\_BGRA2GRAY

## 5、从灰度空间转换到 RGB 和 BGR 颜色空间

cv::COLOR\_GRAY2RGB  
cv::COLOR\_GRAY2BGR

cv::COLOR\_GRAY2RGBA  
cv::COLOR\_GRAY2BGRA

## 6、RGB 和 BGR 颜色空间与 BGR565 颜色空间之间的转换

```
cv::COLOR_RGB2BGR565  
cv::COLOR_BGR2BGR565  
cv::COLOR_BGR5652RGB  
cv::COLOR_BGR5652BGR  
cv::COLOR_RGBA2BGR565  
cv::COLOR_BGRA2BGR565  
cv::COLOR_BGR5652RGBA  
cv::COLOR_BGR5652BGRA
```

## 7、灰度空间域 BGR565 之间的转换

```
cv::COLOR_GRAY2BGR555  
cv::COLOR_BGR5552GRAY
```

## 8、RGB 和 BGR 颜色空间与 CIE XYZ 之间的转换

```
cv::COLOR_RGB2XYZ  
cv::COLOR_BGR2XYZ  
cv::COLOR_XYZ2RGB  
cv::COLOR_XYZ2BGR
```

## 9、RGB 和 BGR 颜色空间与 YCrCb 色度（YCrCb 空间）之间的转换

```
cv::COLOR_RGB2YCrCb  
cv::COLOR_BGR2YCrCb  
cv::COLOR_YCrCb2RGB  
cv::COLOR_YCrCb2BGR
```

## 10、RGB 和 BGR 颜色空间与 HSV 颜色空间之间的相互转换

```
cv::COLOR_RGB2HSV  
cv::COLOR_BGR2HSV  
cv::COLOR_HSV2RGB  
cv::COLOR_HSV2BGR
```

## 11、RGB 和 BGR 颜色空间与 HLS 颜色空间之间的相互转换

```
cv::COLOR_RGB2HLS  
cv::COLOR_BGR2HLS  
cv::COLOR_HLS2RGB  
cv::COLOR_HLS2BGR
```

## 12、RGB 和 BGR 颜色空间与 CIE Lab 颜色空间之间的相互转换

```
cv::COLOR_RGB2Lab  
cv::COLOR_BGR2Lab  
cv::COLOR_Lab2RGB  
cv::COLOR_Lab2BGR
```

### 13、RGB 和 BGR 颜色空间与 CIE Luv 颜色空间之间的相互转换

```
cv::COLOR_RGB2Luv  
cv::COLOR_BGR2Luv  
cv::COLOR_Luv2RGB  
cv::COLOR_Luv2BGR
```


### 14、Bayer 格式（raw data）向 RGB 或 BGR 颜色空间的转换

```
cv::COLOR_BayerBG2RGB  
cv::COLOR_BayerGB2RGB  
cv::COLOR_BayerRG2RGB  
cv::COLOR_BayerGR2RGB  
cv::COLOR_BayerBG2BGR  
cv::COLOR_BayerGB2BGR  
cv::COLOR_BayerRG2BGR  
cv::COLOR_BayerGR2BGR
```

### 彩色的视频捕捉

```
import numpy as np  
import cv2 as cv  
cap = cv.VideoCapture(0)  
if not cap.isOpened():  
    print("Cannot open camera")  
    exit()  
while True:  
    # Capture frame-by-frame  
    ret, frame = cap.read()  
    # if frame is read correctly ret is True  
    if not ret:  
        print("Can't receive frame (stream end?). Exiting ...")  
        break  
    cv.imshow("Video",frame)  
    if cv.waitKey(1) == ord('q'):  
        break  
# When everything done, release the capture  
cap.release()
```

cv.destroyAllWindows()



摄像头视频显示，以及捕捉录像

代码:

```
import numpy as np
import cv2 as cv
cap = cv.VideoCapture(0)
# Define the codec and create VideoWriter object
fourcc = cv.VideoWriter_fourcc(*'XVID')
out = cv.VideoWriter('c:/output.avi', fourcc, 20.0, (640, 480))
while cap.isOpened():
    ret, frame = cap.read()
    if not ret:
        print("Can't receive frame (stream end?). Exiting ...")
        break
    # frame = cv.flip(frame, 0)
    # write the flipped frame
    out.write(frame)
    cv.imshow('frame', frame)
    if cv.waitKey(1) == ord('q'):
        break
# Release everything if job is finished
cap.release()
out.release()
cv.destroyAllWindows()
```






[https://docs.opencv.org/4.2.0/d6/d00/tutorial\\_py\\_root.html](https://docs.opencv.org/4.2.0/d6/d00/tutorial_py_root.html)

[https://docs.opencv.org/4.2.0/d1/dc5/tutorial\\_background\\_subtraction.html](https://docs.opencv.org/4.2.0/d1/dc5/tutorial_background_subtraction.html)



生成的文件如下：



鼠标绘图测试代码

```
import numpy as np
import cv2 as cv
# mouse callback function
def draw_circle(event,x,y,flags,param):
    if event == cv.EVENT_LBUTTONDOWN:
        cv.circle(img,(x,y),100,(255,0,0),-1)
# Create a black image, a window and bind the function to window
img = np.zeros((512,512,3), np.uint8)
cv.namedWindow('image')
cv.setMouseCallback('image',draw_circle)
while(1):
    cv.imshow('image',img)
    if cv.waitKey(20) & 0xFF == 27:
```

```
        break
cv.destroyAllWindows()
```


绘图：直线，圆，椭圆

[https://docs.opencv.org/4.2.0/dc/da5/tutorial\\_py\\_drawing\\_functions.html](https://docs.opencv.org/4.2.0/dc/da5/tutorial_py_drawing_functions.html)

官网中少了后面的一些代码，添加后就 OK 了


代码如下：

```
import numpy as np
import cv2 as cv
# Create a black image
img = np.zeros((512,512,3), np.uint8)
# Draw a diagonal blue line with thickness of 5 px
cv.line(img,(0,0),(511,511),(255,0,0),5)
cv.rectangle(img,(384,0),(510,128),(0,255,0),3)
cv.circle(img,(447,63), 63, (0,0,255), -1)
cv.ellipse(img,(256,256),(100,50),0,0,180,255,-1)
pts = np.array([[10,5],[20,30],[70,20],[50,10]], np.int32)
pts = pts.reshape((-1,1,2))
cv.polylines(img,[pts],True,(0,255,255))
cv.namedWindow('image')
while(1):
    cv.imshow('image',img)
    if cv.waitKey(20) & 0xFF == 27:
        break
cv.destroyAllWindows()
```





## How to Use Background Subtraction Methods



```
from __future__ import print_function
import cv2 as cv
import argparse
parser = argparse.ArgumentParser(description='This program shows how to use
background subtraction methods provided by \
OpenCV. You can process both videos
and images.')
parser.add_argument('--input', type=str, help='Path to a video or a sequence of image.',
default='c:\output.avi')
parser.add_argument('--algo', type=str, help='Background subtraction method (KNN,
MOG2).', default='MOG2')
args = parser.parse_args()
if args.algo == 'MOG2':
    backSub = cv.createBackgroundSubtractorMOG2()
else:
    backSub = cv.createBackgroundSubtractorKNN()
capture = cv.VideoCapture(cv.samples.findFileOrKeep(args.input))
if not capture.isOpened():
    print('Unable to open: ' + args.input)
    exit(0)
while True:
    ret, frame = capture.read()
    if frame is None:
        break

    fgMask = backSub.apply(frame)
```

```

cv.rectangle(frame, (10, 2), (100,20), (255,255,255), -1)
cv.putText(frame, str(capture.get(cv.CAP_PROP_POS_FRAMES)), (15, 15),
            cv.FONT_HERSHEY_SIMPLEX, 0.5 , (0,0,0))

```

```

cv.imshow('Frame', frame)
cv.imshow('FG Mask', fgMask)

```

```

keyboard = cv.waitKey(30)
if keyboard == 'q' or keyboard == 27:
    break

```

```

from __future__ import print_function
import cv2 as cv
import argparse

parser = argparse.ArgumentParser(description='This program shows how to use background subtraction methods provided by \
OpenCV. You can process both videos and images.')
parser.add_argument('--input', type=str, help='Path to a video or a sequence of image.', default='c:\output.avi')
parser.add_argument('--algo', type=str, help='Background subtraction method (KNN, MOG2).', default='MOG2')
args = parser.parse_args()
if args.algo == 'MOG2':
    backSub = cv.createBackgroundSubtractorMOG2()
else:
    backSub = cv.createBackgroundSubtractorKNN()
capture = cv.VideoCapture(cv.samples.findFileOrKeep(args.input))
if not capture.isOpened():
    print('Unable to open: ' + args.input)
    exit(0)
while True:
    ret, frame = capture.read()
    if frame is None:
        break


    fgMask = backSub.apply(frame)

    cv.rectangle(frame, (10, 2), (100,20), (255,255,255), -1)
    cv.putText(frame, str(capture.get(cv.CAP_PROP_POS_FRAMES)), (15, 15),
               cv.FONT_HERSHEY_SIMPLEX, 0.5 , (0,0,0))


    cv.imshow('Frame', frame)
    cv.imshow('FG Mask', fgMask)

    keyboard = cv.waitKey(30)
    if keyboard == 'q' or keyboard == 27:
        break

```



## 图像中查找模式



在 a.jpg 中查找图像 a0.jpg

代码:

```
import cv2 as cv
import numpy as np
from matplotlib import pyplot as plt
img = cv.imread('c:/a.jpg',0)
img2 = img.copy()
template = cv.imread('c:/a0.jpg',0)
w, h = template.shape[::-1]
# All the 6 methods for comparison in a list
methods = ['cv.TM_CCOEFF', 'cv.TM_CCOEFF_NORMED', 'cv.TM_CCORR',
           'cv.TM_CCORR_NORMED', 'cv.TM_SQDIFF', 'cv.TM_SQDIFF_NORMED']
for meth in methods:
    img = img2.copy()
    method = eval(meth)
    # Apply template Matching
    res = cv.matchTemplate(img,template,method)
    min_val, max_val, min_loc, max_loc = cv.minMaxLoc(res)
    # If the method is TM_SQDIFF or TM_SQDIFF_NORMED, take minimum
```



```
if method in [cv.TM_SQDIFF, cv.TM_SQDIFF_NORMED]:
    top_left = min_loc
else:
    top_left = max_loc
bottom_right = (top_left[0] + w, top_left[1] + h)
cv.rectangle(img, top_left, bottom_right, 122, 2)
plt.subplot(121), plt.imshow(res, cmap = 'gray_r')
plt.title('Matching Result'), plt.xticks([]), plt.yticks([])
plt.subplot(122), plt.imshow(img, cmap = 'gray_r')
plt.title('Detected Point'), plt.xticks([]), plt.yticks([])
plt.suptitle(meth)
plt.show()
```

```
a1.py - C:\Python\Python38\python (3.8.1)
File Edit Format Run Options Window Help
import cv2 as cv
import numpy as np
from matplotlib import pyplot as plt
img = cv.imread('c:/a.jpg',0)
img2 = img.copy()
template = cv.imread('c:/a0.jpg',0)
w, h = template.shape[::-1]
# All the 6 methods for comparison in a list
methods = ['cv.TM_CCOEFF', 'cv.TM_CCOEFF_NORMED', 'cv.TM_CCORR',
           'cv.TM_CCORR_NORMED', 'cv.TM_SQDIFF', 'cv.TM_SQDIFF_NORMED']
for meth in methods:
    img = img2.copy()
    method = eval(meth)
    # Apply template Matching
    res = cv.matchTemplate(img,template,method)
    min_val, max_val, min_loc, max_loc = cv.minMaxLoc(res)
    # If the method is TM_SQDIFF or TM_SQDIFF_NORMED, take minimum
    if method in [cv.TM_SQDIFF, cv.TM_SQDIFF_NORMED]:
        top_left = min_loc
    else:
        top_left = max_loc
    bottom_right = (top_left[0] + w, top_left[1] + h)
    cv.rectangle(img,top_left, bottom_right, 122, 2)
    plt.subplot(121),plt.imshow(res,cmap = 'gray_r')
    plt.title('Matching Result'), plt.xticks([], plt.yticks([]))
    plt.subplot(122),plt.imshow(img,cmap = 'gray_r')
    plt.title('Detected Point'), plt.xticks([], plt.yticks([]))
    plt.suptitle(meth)
    plt.show()
```

Figure 1

cv.TM\_CCOEFF

Matching Result



Detected Point



```
a1.py - C:\Python\Python38\python (3.8.1)
File Edit Format Run Options Window Help
import cv2 as cv
import numpy as np
from matplotlib import pyplot as plt
img = cv.imread('c:/a.jpg',0)
img2 = img.copy()
template = cv.imread('c:/a0.jpg',0)
w, h = template.shape[::-1]
# All the 6 methods for comparison in a list
methods = ['cv.TM_CCOEFF', 'cv.TM_CCOEFF_NORMED', 'cv.TM_CCORR',
           'cv.TM_CCORR_NORMED', 'cv.TM_SQDIFF', 'cv.TM_SQDIFF_NORMED']
for meth in methods:
    img = img2.copy()
    method = eval(meth)
    # Apply template Matching
    res = cv.matchTemplate(img,template,method)
    min_val, max_val, min_loc, max_loc = cv.minMaxLoc(res)
    # If the method is TM_SQDIFF or TM_SQDIFF_NORMED, take minimum
    if method in [cv.TM_SQDIFF, cv.TM_SQDIFF_NORMED]:
        top_left = min_loc
    else:
        top_left = max_loc
    bottom_right = (top_left[0] + w, top_left[1] + h)
    cv.rectangle(img,top_left, bottom_right, 122, 2)
    plt.subplot(121),plt.imshow(res,cmap = 'gray_r')
    plt.title('Matching Result'), plt.xticks([]), plt.yticks([])
    plt.subplot(122),plt.imshow(img,cmap = 'gray_r')
    plt.title('Detected Point'), plt.xticks([]), plt.yticks([])
    plt.suptitle(meth)
    plt.show()
```

cv.TM\_CCOEFF\_NORMED

Matching Result



Detected Point




```
a1.py - C:\Python\Python38\python (3.8.1)
File Edit Format Run Options Window Help

import cv2 as cv
import numpy as np
from matplotlib import pyplot as plt
img = cv.imread('c:/a.jpg',0)
img2 = img.copy()
template = cv.imread('c:/a0.jpg',0)
w, h = template.shape[::-1]
# All the 6 methods for comparison in a list
methods = ['cv.TM_CCOEFF', 'cv.TM_CCOEFF_NORMED', 'cv.TM_CCORR',
           'cv.TM_CCORR_NORMED', 'cv.TM_SQDIFF', 'cv.TM_SQDIFF_NORMED']
for meth in methods:
    img = img2.copy()
    method = eval(meth)
    # Apply template Matching
    res = cv.matchTemplate(img,template,method)
    min_val, max_val, min_loc, max_loc = cv.minMaxLoc(res)
    # If the method is TM_SQDIFF or TM_SQDIFF_NORMED, take minimum
    if method in [cv.TM_SQDIFF, cv.TM_SQDIFF_NORMED]:
        top_left = min_loc
    else:
        top_left = max_loc
    bottom_right = (top_left[0] + w, top_left[1] + h)
    cv.rectangle(img,top_left, bottom_right, 122, 2)
    plt.subplot(121),plt.imshow(res,cmap = 'gray_r')
    plt.title('Matching Result'), plt.xticks([], plt.yticks([]))
    plt.subplot(122),plt.imshow(img,cmap = 'gray_r')
    plt.title('Detected Point'), plt.xticks([], plt.yticks([]))
    plt.suptitle(meth)
    plt.show()
```



```
a1.py - C:\Python\Python38\python (3.8.1)
File Edit Format Run Options Window Help

import cv2 as cv
import numpy as np
from matplotlib import pyplot as plt
img = cv.imread('c:/a.jpg',0)
img2 = img.copy()
template = cv.imread('c:/a0.jpg',0)
w, h = template.shape[::-1]
# All the 6 methods for comparison in a list
methods = ['cv.TM_CCOEFF', 'cv.TM_CCOEFF_NORMED', 'cv.TM_CCORR',
           'cv.TM_CCORR_NORMED', 'cv.TM_SQDIFF', 'cv.TM_SQDIFF_NORMED']
for meth in methods:
    img = img2.copy()
    method = eval(meth)
    # Apply template Matching
    res = cv.matchTemplate(img,template,method)
    min_val, max_val, min_loc, max_loc = cv.minMaxLoc(res)
    # If the method is TM_SQDIFF or TM_SQDIFF_NORMED, take minimum
    if method in [cv.TM_SQDIFF, cv.TM_SQDIFF_NORMED]:
        top_left = min_loc
    else:
        top_left = max_loc
    bottom_right = (top_left[0] + w, top_left[1] + h)
    cv.rectangle(img,top_left, bottom_right, 122, 2)
    plt.subplot(121),plt.imshow(res,cmap = 'gray_r')
    plt.title('Matching Result'), plt.xticks([], plt.yticks([]))
    plt.subplot(122),plt.imshow(img,cmap = 'gray_r')
    plt.title('Detected Point'), plt.xticks([], plt.yticks([]))
    plt.suptitle(meth)
    plt.show()
```



```
a1.py - C:\Python\Python38\python (3.8.1)
File Edit Format Run Options Window Help
import cv2 as cv
import numpy as np
from matplotlib import pyplot as plt
img = cv.imread('c:/a.jpg',0)
img2 = img.copy()
template = cv.imread('c:/a0.jpg',0)
w, h = template.shape[::-1]
# All the 6 methods for comparison in a list
methods = ['cv.TM_CCOEFF', 'cv.TM_CCOEFF_NORMED', 'cv.TM_CCORR',
           'cv.TM_CCORR_NORMED', 'cv.TM_SQDIFF', 'cv.TM_SQDIFF_NORMED']
for meth in methods:
    img = img2.copy()
    method = eval(meth)
    # Apply template Matching
    res = cv.matchTemplate(img,template,method)
    min_val, max_val, min_loc, max_loc = cv.minMaxLoc(res)
    # If the method is TM_SQDIFF or TM_SQDIFF_NORMED, take minimum
    if method in [cv.TM_SQDIFF, cv.TM_SQDIFF_NORMED]:
        top_left = min_loc
    else:
        top_left = max_loc
    bottom_right = (top_left[0] + w, top_left[1] + h)
    cv.rectangle(img,top_left, bottom_right, 122, 2)
    plt.subplot(121),plt.imshow(res,cmap = 'gray_r')
    plt.title('Matching Result'), plt.xticks([]), plt.yticks([])
    plt.subplot(122),plt.imshow(img,cmap = 'gray_r')
    plt.title('Detected Point'), plt.xticks([]), plt.yticks([])
    plt.suptitle(meth)
    plt.show()
```


cv.TM\_SQDIFF

Matching Result



Detected Point





cv.TM\_SQDIFF\_NORMED

Matching Result



Detected Point



```

methods = ['cv.TM_CCOEFF', 'cv.TM_CCOEFF_NORMED', 'cv.TM_CCORR',
           'cv.TM_CCORR_NORMED', 'cv.TM_SQDIFF', 'cv.TM_SQDIFF_NORMED']

```

六种模式的识别。

CV\_TM\_SQDIFF 平方差匹配法：该方法采用平方差来进行匹配；最好的匹配值为0；匹配越差，匹配值越大。

CV\_TM\_CCORR 相关匹配法：该方法采用乘法操作；数值越大表明匹配程度越好。

CV\_TM\_CCOEFF 相关系数匹配法：1表示完美的匹配；-1表示最差的匹配。

CV\_TM\_SQDIFF\_NORMED 归一化平方差匹配法

CV\_TM\_CCORR\_NORMED 归一化相关匹配法

CV\_TM\_CCOEFF\_NORMED 归一化相关系数匹配法

## 2.匹配算法

TM_SQDIFF	$R(x, y) = \sum_{x', y'} (T(x', y') - I(x + x', y + y'))^2$
TM_SQDIFF_NORMED	$R(x, y) = \frac{\sum_{x', y'} (T(x', y') - I(x + x', y + y'))^2}{\sqrt{\sum_{x', y'} T(x', y')^2 \cdot \sum_{x', y'} I(x + x', y + y')^2}}$
TM_CCORR	$R(x, y) = \sum_{x', y'} (T(x', y') \cdot I(x + x', y + y'))$
TM_CCORR_NORMED	$R(x, y) = \frac{\sum_{x', y'} (T(x', y') \cdot I(x + x', y + y'))}{\sqrt{\sum_{x', y'} T(x', y')^2 \cdot \sum_{x', y'} I(x + x', y + y')^2}}$
TM_CCOEFF	$R(x, y) = \sum_{x', y'} (T'(x', y') \cdot I'(x + x', y + y'))$ <p>where</p> $T'(x', y') = T(x', y') - 1/(w \cdot h) \cdot \sum_{x'', y''} T(x'', y'')$ $I'(x + x', y + y') = I(x + x', y + y') - 1/(w \cdot h) \cdot \sum_{x'', y''} I(x + x'', y + y'')$
TM_CCOEFF_NORMED	$R(x, y) = \frac{\sum_{x', y'} (T'(x', y') \cdot I'(x + x', y + y'))}{\sqrt{\sum_{x', y'} T'(x', y')^2 \cdot \sum_{x', y'} I'(x + x', y + y')^2}}$

分别是：计算平方不同、计算归一化平方不同、计算相关性、计算归一化相关性、计算相关系数、计算归一化相关